USB2.0 to RS232(Enhanced) Serial Manual -

rate, serial port conforms to RS232 standard interface, wire with aluminum foil and 64B tin copper braided mesh double shield, strong anti-interference, signal more stable. It can be used in cash register, $\,$ LED display, nc machine tool, industrial machine, industrial instrument, bar code printer and other RS232 serial port

I.Product introduction

USB2.0 to RS232 Serial

(1) support baud rate of 300~1000000bps.

II. Specification

equipment.

(2) support super large data send and receive buffer function: 256 byte send, 768 byte receive. (3) Support data bits: 7, 8, 9, stop bits: 1, 1.5, 2, Check bits: Even, None, Odd, Mark, Space. (4) automatic hardware (RTS/CTS or DTR/DSR) flow control. (5) support handshake protocol control, MODEM contact signal 1:DCD,

This product is an enhanced universal asynchronous transmission standard USB2.0 to RS232 serial port product, USB interface fully conforms to full speed USB2.0 specification to support full speed data transmission

2:RXD, 3:TXD, 4:DTR, 5:GND, 6:DSR, 7:RTS, 8:CTS, 9:RI. (6) Anti-electromagnetic interference design, self-powered USB bus, plug and play.

(7) ESD protection of circuit integration: ±15KV iec 1000-4-2 air gap discharge ±8KV iec 1000-4-2 contact discharge.

Ⅲ . Interface description

6

6

7

8

9

10

desktop

V. Product accessories

(1) USB2.0 to RS232 Cable/1 PCS (2) Product scan code card/1 PCS

comput laptop DB9male

USB 2.0

IV. Connection diagram

(8) support Windows XP, Win7, Win8, Win10, Mac system.

interface type Transmission direction number Function Description DCD 0 Carrier detection 2 RXD Data reception DB9male 3 TXD 0 Data transmission 4 Data terminal ready DTR 0

GND

DSR

RTS

CTS

0

Ground (GND)

Data device


Request to send

Clear send Ringing

indication

USB2.0 A male

cashier



application



_instruction.

Note: The connection diagram is for reference only.

I . Introduction to the installation of drive steps (1)Scan code card to download and install the driver through Dtech website. Download the driver installation package and unzip, click on the "windows" folder to start installing the driver (the following instructions are all operated on the win7 system), as shown in the figure:

Step two: After clicking "windows", choose the "PL2303-Prolific-DriverInstaller-v1200" compression pack

■ PL2303_Prolific_DriverInstaller_v1200 2020/12/7 17:12 好压 ZIP 压缩文件

double click the

and decompress it.

Step three: After decompression,

application window as shown below.

Step four: Double click the running program, you will pop up the installation dialog box, click next, as shown below.

Step five: After clicking on "next step", the system will automatically complete the process of installation, and after the end of the installation process, click the "complete" in

2

the dialog box to end the installation process:

.....

* Favorites



Rename **Properties**

factory to replace. Figure:

○ 性能 益 设备管理器 本 2章 存储

and pops "COM".

If you insert the serial port line in the "device manager", not to see the driver, but to display "unknown Device", then replace the computer and USB test, if this is the case, it may

Step three: See the device manager set to identify the COM slogan, may not be able to connect with the communication device, the next figure is a LED display application software, the software can set the port change COM slogan, the same

配置控制卡 內部物数

Step four: If there are no more COM ports in the software, or the selected COM port is still unable to connect, then you need to change the COM number in the device manager, right click the "COM" port in the map, and select the attributes

as device manager of the COM port:

节目1 図 文本1 以 时间1

such as the figure:

"confirm":

be a serial line failure, it is recommended to return to the

Step two: Insert the serial port line into the computer USB interface, select "device manager" in "management", in "device manager", "port" this item cansee that the serial port line has been installed,


```
Shared
Shared
Local I
Perform
Device
Storage
After clicking "attribute", the first shot is a regular column.
The status of the device shows "this device is working
properly". The driver installation does not appear to be a
problem, and then click "port settings", such as:
```

If the user still needs to change the port of the serial port, then click "advanced settings" in the port settings:

In the "advanced settings", you can see the "COM port" setting. Click the "COM port number" option to change the

port number of the serial port:

After clicking "port settings", "bit / second" is the parameter setting of the baud rate. If you need to change, you can change it for the baud rate of the serial line A, and then click



compatibility problem.

User a Dis Agend User

Intena

Repair

Product Warranty Card Customer Information

elephone:	
address:	
ributor:	
y address:	
elephone:	Dealer stamp valid

Model: Date of purchasel:

stributo	or:						
cy add	ress:						
telephone:		Dealer stamp valid					
ance Records							
rtimes	Dat	е	Fault	Treatment measures	Repair work NO		