Type-C+USB2.0 to RS232/ RS485/RS422 Serial Cable
——— User manual

download the product driver file.

I. Product Introduction

- Supports RS232, RS485, RS422 4 wire, 2 wire, industry-level protection function of all 15 circuits, standard baud rate of 50-921600bps, 5 kV electrostatic protection, meeting industrial control systems, security control systems, electronic systems, traffic control systems, and other industrial environments with high reliability requirements.

II. Product Parameters

- RS485/422 communication rate: 5Mbps to 5Mbps
- RS232 communication rate: 50bps to 921600bps
- RS485 and receiver up to 256 RS485 devices
- Data bits: 5,6,7,8
- Stop bits: 1,1.5,2; Odd, None, Mark, Space
- Flow ctrl: X-On / X-Off
- Supports Windows, Linux, Android, MacOS operating System
- 2.4KV, ESD15KV 8 Contact discharge
- Cable length: 1.2m, 1.5m, 2m, 3m, 5m
- Cable: Double-shielded copper wire braided
- Support 5V. Power output (the output current is determined by the computer USB port)
- Standard interface with other industrial RS232/485/422 standards
- Operating temperature: -40°C to 85°C, storage temperature: -40°C to 85°C
- Up recommended: -20°C to 85°C, relative humidity is 5% to 95%

III. Installation Details



DB9 Male Pin definition

Pin	Definition	Pin	Definition
❶	RS485-	❻	GND
❷	RS485+	❼	RS232 RXD
❸	RS422R-	❽	RS232 TXD
❹	RS422R+	❾	DC 5V

Terminal pin definition


Position	Definition	Position	Definition
RS485/422 Interface	RS485/422 Interface	DC 5V	Power output
RS485/422 Interface	RS485/422 Interface	GND	Grounded
RS422R+	RS422 receiver	RS232 TX	RS232 receiver
RS422R-	RS422 receiver	RS232 RX	RS232 receiver

IV. Installation Matters

RS485 Communication diagram



RS422 Communication diagram



V. Packaging And Accessories

- Product *1
- Terminal board *1

Type-C+USB2.0 to RS232/ RS485/RS422 Serial Cable ——— Manual

Step 1: Find the shortcut on the "Computer" icon, click the "right mouse button", and then click "Properties".




Step 2 : Click the "Device Manager".



Step 3: When the driver is not installed, you can see the following information in the "Device Manager".



Step 4: Before installing the driver, check the computer system



Step 5: After confirming the system, open the "Driver CD" that comes with the product, then click the "CH343SER.EXE" file.

Mac_OSX	2018/7/23 16:50
Windows XP_7_8_8.1 (x64_x86)	2018/7/23 16:50
Windows XP_7_8_8.1 (x64_x86)	2018/7/23 16:50

Step 6 : Select the corresponding system file to install (take windows 7_8.1 for example as an example).



Step 7 : Enter the folder and double-click the "CH343SerialProvider_zhcn" file.



Step 8 : Please click"Next"



Step 9 : Select"I accept this agreement",and then click"Next"



Step 10: The driver is being installed, please wait.



Step 11: The driver installation has been completed, please click "Finish"



If you need to change the port number, please do as follows:

Step 1: Open the device manager and find the port number

Step 2: right-click"Properties"

Step 3: click"port settings"



Step 4: click "Advanced"



Step 5 : click "COM Port Number"

Step 6: Select the port number you want to modify (take port COM5 as an example)

Step 7: After selecting the port "COM5", click "OK"

Step 8: Click "OK"

Step 9: At this time,the following error you see that the port has been modified to port "COM5",then click "OK" to confirm.



Product Warranty Card

Customer information

Model	
Date of purchase	
User Machine	
User address	
Distributor	
Agency address	
User telephone	Dealer stamp valid

Maintenance Records

Repair date	Fault	Treatment measures	Repair user unit

The above products are guaranteed for one year, and other products are guaranteed for six months. Within the warranty period, the product will be repaired free of charge if the problem is not caused by the buyer (if applicable).